

**Перечень компонентов, запрещенных к установке на воздушные суда**

Согласно информации EASA OC-EASA-2026002221, опубликованной 26.03.2026, произошло хищение компонентов и оборудования для турбореактивных двигателей моделей CFM56, IAE V2500, PW1100 и RB211.

Федеральное агентство воздушного транспорта рекомендует владельцам, эксплуатантам и организациям по техническому обслуживанию воздушных судов, оборудованных указанными моделями двигателей, проверить компоненты, установленные на воздушные суда, а также находящиеся в наличии на складах, на предмет соответствия партийных и серийных номеров компонентов приведенному ниже перечню.

В случае обнаружения данных компонентов на борту воздушного судна или хранящихся на складе, рекомендуется снять компонент или переместить в карантин для предотвращения установки, проинформировать соответствующим образом Федеральное агентство воздушного транспорта.

P/N	S/N	DENOMINATION	ENGINE MODEL
10-631045-2	UNJNP661	TFN-26 / TFN-30 IGNITION EXCITERS	CFM56-5B
11-841193-4	YP027920-M	OIL/FUEL HEAT EXCHANGER	CFM56-5B
1211313-010	APMTC868	ACTUATOR VARIABLE STATOR	CFM56-5B
121762-3	YG535928-3	MASTER FLEXIBLE SHAFT	CFM56-5B
121762-4	YG535928-B	FLEXIBLE SHAFT	CFM56-5B
1358M35G02	WDMA6017	SEAL STAT. OUTER HPT	CFM56-5B
1358M35G02	WESC4582	SEAL STAT. OUTER HPT	CFM56-5B
1361M13P01	TEJD5018	SEAL-ROTATING N° 3 BRG	CFM56-5B
1364M91P05	FCAT3564	BEARING, ROLLER NO.3	CFM56-5B
1386M56P03	GWNOR8DD	FRONT SHAFT	CFM56-5B
1386M56P03	GWNOM7AF	FRONT SHAFT	CFM56-5B
1386M56P03	GWNON1M5	FRONT SHAFT	CFM56-5B
1386M56P03	GWNORDKR	FRONT SHAFT	CFM56-5B
1386M56P03	GWNORH88	FRONT SHAFT	CFM56-5B
144-183-000-021	DJ895453-A	N1 VIBRATION SENSOR	CFM56-5B
144-405-000-033	27002	VIBRATION TRASDUCER TRF BEARING No 5	CFM56-5B
144-405-000-033	29165	VIBRATION TRASDUCER TRF BEARING No 5	CFM56-5B
144-405-000-033	YV192149-T	VIBRATION TRASDUCER TRF BEARING No 5	CFM56-5B
144-405-000-033	26808	VIBRATION TRASDUCER TRF BEARING No 5	CFM56-5B
144-405-000-033	28207	VIBRATION TRASDUCER TRF BEARING No 5	CFM56-5B
1460M52P03	FCAG0835	BEARING, BALL THRUST NO.3	CFM56-5B
1460M52P03	FCAG1219	BEARING, BALL THRUST NO.3	CFM56-5B
1460M52P03	FCAR8146	BEARING, BALL THRUST NO.3	CFM56-5B
1460M52P03	FCAR8149	BEARING, BALL THRUST NO.3	CFM56-5B
1476M79P02	52309	DAMPER FWD SLEEVE	CFM56-5B
1476M79P02	0748204608	DAMPER FWD SLEEVE	CFM56-5B
1476M79P02	18-94292/1	DAMPER FWD SLEEVE	CFM56-5B
1476M79P03	15-76727/1/02	DAMPER FWD SLEEVE	CFM56-5B
1498M43P07	GWNOMDLH	DISK HPT	CFM56-5B
1498M43P07	GWNOM6R1	DISK HPT	CFM56-5B
1498M43P07	GWNON3T7	DISK HPT	CFM56-5B
1558M31G04	GWN0A63M	SPOOL STG. 1-2	CFM56-5B

Перечень компонентов, запрещенных к установке на воздушные суда

1558M31G07	GWN0W8A8	SPOOL STG. 1-2	CFM56-5B
1558M31G07	GWN0R852	SPOOL STG. 1-2	CFM56-5B
1558M31G07	GWN0M74L	SPOOL STG. 1-2	CFM56-5B
1558M31G07	GWN0N37F	SPOOL STG. 1-2	CFM56-5B
1558M31G07	GWN0RJ5E	SPOOL STG. 1-2	CFM56-5B
1558M31G07	GWN0RJGW	SPOOL STG. 1-2	CFM56-5B
1559M40G03	FBJM4848	CASE REAR HPC	CFM56-5B
1559M40G03	CDACTF5P	CASE REAR HPC	CFM56-5B
1590M59P01	XAEG0567	DISK STG. 3	CFM56-5B
1665M98P02	MDAKC675	BEARING, BALL THRUST NO.3	CFM56-5B
1795M36P02	TMT150AA	SEAL ROTATING HPT	CFM56-5B
1795M36P02	TMT6Y604	SEAL ROTATING HPT	CFM56-5B
1853M10G04	PPBHB140	SEAL, STA NO.3 BRG	CFM56-5B
1853M10G04	CTDAJ180	SEAL, STA NO.3 BRG	CFM56-5B
1853M10G04	CTDD7NLB	SEAL, STA NO.3 BRG	CFM56-5B
1853M10G04	CTDJ6954	SEAL, STA NO.3 BRG	CFM56-5B
1853M10G04	CTDD8MVM	SEAL, STA NO.3 BRG	CFM56-5B
1853M10G04	PPBMC158	SEAL, STA NO.3 BRG	CFM56-5B
1853M10G04	CTDAR488	SEAL, STA NO.3 BRG	CFM56-5B
1864M90P04	TMT1H3E3	REAR SHAFT HPT	CFM56-5B
1864M90P04	TMTA9124	REAR SHAFT HPT	CFM56-5B
1864M90P04	TMTA4289	REAR SHAFT HPT	CFM56-5B
1864M90P04	TMT6P741	REAR SHAFT HPT	CFM56-5B
1864M90P04	TMT7N211	REAR SHAFT HPT	CFM56-5B
1864M90P04	TMT7U678	REAR SHAFT HPT	CFM56-5B
1864M90P04	TMTA5215	REAR SHAFT HPT	CFM56-5B
1968M44G06	FCW15796	LINER-OUTER COMBUSTION	CFM56-5B
1968M59G01	EGTB8463	OUTER COLW	CFM56-5B
1968M64G01	GGM92D3N	LINER INNER COMB CHAMBER	CFM56-5B
2002M15P01	NCE0416V	RETAINER BLADE HPT REAR	CFM56-5B
2002M15P01	NCE6802W	RETAINER BLADE HPT REAR	CFM56-5B
2002M15P01	FDU3066C	RETAINER BLADE HPT REAR	CFM56-5B
2048M20G03	GWN0M751	SPOOL STG. 4-9	CFM56-5B
2048M20G03	GWN0N3TH	SPOOL STG. 4-9	CFM56-5B
2048M20G04	GWN10K52	SPOOL STG. 4-9	CFM56-5B
2048M20G04	GWN0R8H6	SPOOL STG. 4-9	CFM56-5B
2048M20G04	GWN0RJD9	SPOOL STG. 4-9	CFM56-5B
2048M21P03	XAEB284	FRONT SHAFT HPT	CFM56-5B
2048M21P03	XAER3491	FRONT SHAFT HPT	CFM56-5B
2048M21P03	XAES8594	FRONT SHAFT HPT	CFM56-5B
2048M21P03	XAEW4717	FRONT SHAFT HPT	CFM56-5B
2086M14G02	MDK19CE6	NOZZLE HPT STATOR	CFM56-5B
2116M20P02	TMT5CK61	SEAL ROTATING HPT	CFM56-5B
2116M20P02	TMT5CH02	SEAL ROTATING HPT	CFM56-5B
2116M20P02	TMT5CS99	SEAL ROTATING HPT	CFM56-5B
2116M23P01	XAEB376	DISK STG. 3	CFM56-5B
2116M23P01	XAEB5212	DISK STG. 3	CFM56-5B
2116M23P01	XAER4528	DISK STG. 3	CFM56-5B
2116M23P01	XAET4329	DISK STG. 3	CFM56-5B
2116M25P01	GFF5G2WA	SEAL ROTATING CDP	CFM56-5B
2116M25P01	GFF5GWCL	SEAL ROTATING CDP	CFM56-5B
2116M25P01	GFF5F2WD	SEAL ROTATING CDP	CFM56-5B

Перечень компонентов, запрещенных к установке на воздушные суда

2116M25P01	GFF5FFLA	SEAL ROTATING CDP	CFM56-5B
2116M25P01	GFF5H51D	SEAL ROTATING CDP	CFM56-5B
2256M23G03	GGM9CJ32	LINER-INNER COMBUSTION	CFM56-5B
2257M42G01	GGM8RF7R	LINER-INNER COMBUSTION	CFM56-5B
238-0808-507	SP0000294539/15-6	DRAIN MASTER	CFM56-5B
2410M49P01	GWN0R8GH	DISK HPT	CFM56-5B
2410M49P01	GWN0RJ8G	DISK HPT	CFM56-5B
2410M50P02	XAEC5735	SEAL ROTATING HPT	CFM56-5B
2410M50P02	TMT5DS44	SEAL ROTATING HPT	CFM56-5B
2410M50P02	TMT3A245	SEAL ROTATING HPT	CFM56-5B
2410M51P01	FDU5350G	RETAINER BLADE HPT REAR	CFM56-5B
2410M51P01	FDU6035J	RETAINER BLADE HPT REAR	CFM56-5B
301-480-320-0	EB106118	BEARING, BALL	CFM56-5B
305-115-306-0	EB108892	BEARING, BALL	CFM56-5B
305-115-306-0	EB193111	BEARING, BALL	CFM56-5B
305-115-306-0	EB193537	BEARING, BALL	CFM56-5B
305-115-306-0	EB193539	BEARING, BALL	CFM56-5B
305-115-306-0	EB670468	BEARING, BALL	CFM56-5B
305-355-718-0	DN080848	BEARING, 4-RLR	CFM56-5B
305-355-718-0	DC897938-M	BEARING, 4-RLR	CFM56-5B
305-355-718-0	DN080849	BEARING, 4-RLR	CFM56-5B
305-355-718-0	DC551690-8	BEARING, 4-RLR	CFM56-5B
305-355-718-0	DE370086-6	BEARING, 4-RLR	CFM56-5B
305-355-718-0	DE945899	BEARING, 4-RLR	CFM56-5B
305-355-718-0	DY726943	BEARING, 4-RLR	CFM56-5B
305-355-720-0	RR17472	BEARING, 4-RLR	CFM56-5B
3282970-4	YG091034-E	VBV STOP MECHANISM	CFM56-5B
3282970-4	YG092783-5	VBV STOP MECHANISM	CFM56-5B
3282970-4	YG093241-W	VBV STOP MECHANISM	CFM56-5B
3282970-4	YG091215-C	VBV STOP MECHANISM	CFM56-5B
3282970-4	YG092589-1	VBV STOP MECHANISM	CFM56-5B
3282970-4	YG093865-H	VBV STOP MECHANISM	CFM56-5B
3282970-4	YG094246-8	VBV STOP MECHANISM	CFM56-5B
3282970-4	EM609107-1	VBV STOP MECHANISM	CFM56-5B
3282970-4	EM610122-P	VBV STOP MECHANISM	CFM56-5B
329695-5	WCP0081J	HIGH PRESSURE TURBINE CLEARANCE VALVE	CFM56-5B
335-352-303-0	DK254482	BEARING, 4-RLR	CFM56-5B
335-352-303-0	DE833240	BEARING, 4-RLR	CFM56-5B
335-352-303-0	DK254128	BEARING, 4-RLR	CFM56-5B
336-001-804-0	PA959818	DISK-LPT STG 1	CFM56-5B
336-001-909-0	PA924695	DISK-LPT STG 2	CFM56-5B
336-002-006-0	PA953179	DISK-LPT STG 3	CFM56-5B
336-002-105-0	PA924213	DISK-LPT STG 4	CFM56-5B
336-009-801-0	DH980660	SEAL-ROTATING OIL N° 4 BRG	CFM56-5B
336-009-801-0	DF822946	SEAL-ROTATING OIL N° 4 BRG	CFM56-5B
336-013-101-0	DH979734	RING-SUPPORT	CFM56-5B
336-024-708-0	DB853875	COVER ASSY, OIL INLET	CFM56-5B
336-026-302-0	DH706339	SEAL-SUPPORT	CFM56-5B
337-108-520-0	DA472305	SEPARATOR-AIR OIL	CFM56-5B
337-108-551-0	DB685180	SEPARATOR-AIR OIL	CFM56-5B
337-108-551-0	DB067915	SEPARATOR-AIR OIL	CFM56-5B
337-108-551-0	DB683580-6	SEPARATOR-AIR OIL	CFM56-5B

Перечень компонентов, запрещенных к установке на воздушные суда

337-108-551-0	DB679068-2	SEPARATOR-AIR OIL	CFM56-5B
337-108-551-0	DB679914-Y	SEPARATOR-AIR OIL	CFM56-5B
337-108-551-0	DD980327-2	SEPARATOR-AIR OIL	CFM56-5B
337-108-551-0	DB684008	SEPARATOR-AIR OIL	CFM56-5B
337-108-551-0	DD024186-T	SEPARATOR-AIR OIL	CFM56-5B
338-001-504-0	BB089135	FAN DISK	CFM56-5B
338-001-906-0	BC224265	BOOSTER SPOOL	CFM56-5B
338-001-906-0	DC095521	BOOSTER SPOOL	CFM56-5B
338-002-114-0	BC016437	BLADE-FAN ROTOR STG1	CFM56-5B
338-002-114-0	BC175539	BLADE-FAN ROTOR STG1	CFM56-5B
338-002-114-0	BC317648	BLADE-FAN ROTOR STG1	CFM56-5B
338-002-114-0	PA009394	BLADE-FAN ROTOR STG1	CFM56-5B
338-002-114-0	DC566463	BLADE-FAN ROTOR STG1	CFM56-5B
338-002-114-0	DD113951	BLADE-FAN ROTOR STG1	CFM56-5B
338-002-114-0	DJ269389	BLADE-FAN ROTOR STG1	CFM56-5B
338-002-114-0	DJ277402	BLADE-FAN ROTOR STG1	CFM56-5B
338-002-114-0	PA289172	BLADE-FAN ROTOR STG1	CFM56-5B
338-002-114-0	PA299585	BLADE-FAN ROTOR STG1	CFM56-5B
338-002-114-0	PA494120	BLADE-FAN ROTOR STG1	CFM56-5B
338-002-114-0	PA497834	BLADE-FAN ROTOR STG1	CFM56-5B
338-002-114-0	PA515046	BLADE-FAN ROTOR STG1	CFM56-5B
338-002-114-0	PA537600	BLADE-FAN ROTOR STG1	CFM56-5B
338-003-106-0	LA020562	VANE ASSY FAN BSTR STG 1	CFM56-5B
338-003-106-0	PC072443	VANE ASSY FAN BSTR STG 1	CFM56-5B
338-003-205-0	MA240161	VANE-ASSY BOOSTER STG2	CFM56-5B
338-003-509-0	LA088791	VANE ASSY BOOSTER STG5	CFM56-5B
338-010-005-0	PA830819	LPT SHAFT	CFM56-5B
338-010-005-0	BB576758	LPT SHAFT	CFM56-5B
338-010-005-0	PA896328	LPT SHAFT	CFM56-5B
338-010-005-0	DH950422	LPT SHAFT	CFM56-5B
338-010-005-0	PA955473	LPT SHAFT	CFM56-5B
338-010-601-0	DE802632	FAN SHAFT	CFM56-5B
338-010-601-0	DB687903	FAN SHAFT	CFM56-5B
338-063-704-0	MA100712	SEAL, STA BRG 1	CFM56-5B
338-063-704-0	MA132098-N	SEAL, STA BRG 1	CFM56-5B
338-063-704-0	MA100398	SEAL, STA BRG 1	CFM56-5B
338-063-704-0	MA182274	SEAL, STA BRG 1	CFM56-5B
338-063-705-0	MA446165	SEAL, STA BRG 1	CFM56-5B
338-063-705-0	MA307462	SEAL, STA BRG 1	CFM56-5B
338-063-705-0	MA204202	SEAL, STA BRG 1	CFM56-5B
338-063-705-0	MA192773	SEAL, STA BRG 1	CFM56-5B
338-063-705-0	MA256372-7	SEAL, STA BRG 1	CFM56-5B
338-063-705-0	MA232807	SEAL, STA BRG 1	CFM56-5B
338-063-705-0	MA257975	SEAL, STA BRG 1	CFM56-5B
338-063-705-0	MA232519	SEAL, STA BRG 1	CFM56-5B
338-102-912-0	LA081337	FRAME ASSY-LPT	CFM56-5B
338-108-608-0	DA906094	NOZZLE SEGMENT-LPT STG 1	CFM56-5B
338-108-608-0	DA909771	NOZZLE SEGMENT-LPT STG 1	CFM56-5B
338-108-608-0	DP310902	NOZZLE SEGMENT-LPT STG 1	CFM56-5B
338-108-608-0	DA903565	NOZZLE SEGMENT-LPT STG 1	CFM56-5B
338-108-608-0	DP307046-2	NOZZLE SEGMENT-LPT STG 1	CFM56-5B
338-108-608-0	DP309169	NOZZLE SEGMENT-LPT STG 1	CFM56-5B

Перечень компонентов, запрещенных к установке на воздушные суда

338-108-708-0	BA98631A	NOZZLE SEGMENT-LPT STG 1	CFM56-5B
338-108-708-0	BB74421B	NOZZLE SEGMENT-LPT STG 1	CFM56-5B
338-111-003-0	DC414071	FLANGE-FRONT	CFM56-5B
338-111-202-0	53325	FLANGE-INTMD	CFM56-5B
338-117-407-0	DE449592	LPT CASE ASSY	CFM56-5B
338-180-401-0	08W34	TUBE-VENT REAR	CFM56-5B
340-027-507-0	08W18	MANIFOLD-CLG RIGHT	CFM56-5B
340-027-557-0	F697461:314	MANIFOLD-CLG LEFT	CFM56-5B
340-167-902-0	DH451931	BEARING, 4-RLR	CFM56-5B
340-301-702-0	DH705970	LPT ROTOR SUPPORT	CFM56-5B
340-301-702-0	DH707224	LPT ROTOR SUPPORT	CFM56-5B
3505582-65	YG336717-7C	AIR TURBINE ENGINE STARTER	CFM56-5B
41SG381-1	N037108	OIL PRESSURE TRANSMITTER (PRESSURE TRANSDUCER)	CFM56-5B
41SG381-1	J048381	OIL PRESSURE TRANSMITTER (PRESSURE TRANSDUCER)	CFM56-5B
41SG381-1	M010622	OIL PRESSURE TRANSMITTER (PRESSURE TRANSDUCER)	CFM56-5B
5507-910-0	YU090859-L	CHIP DETECTOR	CFM56-5B
6237M106B	80473	VIBRATION TRASDUCER TRF BEARING N° 5	CFM56-5B
6237M106B	80525	VIBRATION TRASDUCER TRF BEARING N° 5	CFM56-5B
642-2003-503	6072NEI	PIN-ATTA	CFM56-5B
642M2000-1	P4560	BEAM, ASSY-FWD ENG MT	CFM56-5B
642W9955-501	68201805	HARNESS ASSY-CORE FIRE DETECTOR CH A	CFM56-5B
642W9956-501	NAS14940	HARNESS ASSY-CORE FIRE DETECTOR CH B	CFM56-5B
6840023E18	PCY037P1	FUEL NOZZLE	CFM56-5B
6840023E18	PCY037P3	FUEL NOZZLE	CFM56-5B
9043110-16	UNKP8361	IGNITION LEAD LEFT	CFM56-5B
9043110-16	UNJ35379	IGNITION LEAD LEFT	CFM56-5B
9043110-16	UNK98424	IGNITION LEAD LEFT	CFM56-5B
9072215-1	L41644	IGNITER PLUG	CFM56-5B
9072215-1	LP7712	IGNITER PLUG	CFM56-5B
9072215-1	LHF707	IGNITER PLUG	CFM56-5B
9072215-1	CHF707	IGNITER PLUG	CFM56-5B
9339M40G05	PPBBS88	SEAL STATIONARY AIR OIL	CFM56-5B
9339M40G05	PPBTC693	SEAL STATIONARY AIR OIL	CFM56-5B
9339M40G05	PPBTE585	SEAL STATIONARY AIR OIL	CFM56-5B
9339M40G05	PPBCCC68	SEAL STATIONARY AIR OIL	CFM56-5B
9339M40G05	PPBLS992	SEAL STATIONARY AIR OIL	CFM56-5B
9339M40G05	PPBCLM53	SEAL STATIONARY AIR OIL	CFM56-5B
9339M40G05	PPBCM98	SEAL STATIONARY AIR OIL	CFM56-5B
9339M40G05	PPBTE967	SEAL STATIONARY AIR OIL	CFM56-5B
9514M54G05	CDAARG4M	DUCT AIR	CFM56-5B
9514M54G05	CDAAPFRN	DUCT AIR	CFM56-5B
9514M54G05	CDAAR16T	DUCT AIR	CFM56-5B
9531M11G02	BOM70221	INNER COWL	CFM56-5B
9541M89P01	FCABG317	BEARING, BALL THRUST	CFM56-5B
9541M89P01	FCAD2344	BEARING, BALL THRUST	CFM56-5B
9542M67P01	ACHA2591	GEAR-BEVEL 47 TOOTH	CFM56-5B
9542M67P01	ACHB2156	GEAR-BEVEL 47 TOOTH	CFM56-5B
9542M67P01	ACHM1672	GEAR-BEVEL 47 TOOTH	CFM56-5B
9972M31G03	ACHE2523	GEAR ASSY-BEVEL 35 TOOTH	CFM56-5B

Перечень компонентов, запрещенных к установке на воздушные суда

9972M33P07	FCAAD948	BEARING ROLLER CYLINDRICAL	CFM56-5B
9972M46G05	WAGBJ876	NUT-LOCKING N° 3 BRG	CFM56-5B
9972M46G05	FFNBK971	NUT-LOCKING N° 3 BRG	CFM56-5B
9972M46G05	FFNBY129	NUT-LOCKING N° 3 BRG	CFM56-5B
9972M46G05	TEJK8460	NUT-LOCKING N° 3 BRG	CFM56-5B
9972M46G05	FFNCM914	NUT-LOCKING N° 3 BRG	CFM56-5B
9972M46G05	TEJ68028	NUT-LOCKING N° 3 BRG	CFM56-5B
9972M46G05	TEJD3907	NUT-LOCKING N° 3 BRG	CFM56-5B
9972M46G05	TEJE8273	NUT-LOCKING N° 3 BRG	CFM56-5B
9972M46G05	TEJ82894	NUT-LOCKING N° 3 BRG	CFM56-5B
9972M46G05	WAGBJ874	NUT-LOCKING N° 3 BRG	CFM56-5B
9972M46G05	FFNCL549	NUT-LOCKING N° 3 BRG	CFM56-5B
9972M46G05	FFNCN684	NUT-LOCKING N° 3 BRG	CFM56-5B
CA170-01	YC370544-E	T495 THERMOCOUPLE WIRING HARNESS	CFM56-5B
CA171-01	YC380206-1	T495 THERMOCOUPLE WIRING HARNESS	CFM56-5B
CA211-00	YC371898-4	T495 THERMOCOUPLE WIRING HARNESS	CFM56-5B
CA211-00	YC376905-8	T495 THERMOCOUPLE WIRING HARNESS	CFM56-5B
CH31900-6	22050077	IGNITER PLUG	CFM56-5B
CH31900-6	23001262	IGNITER PLUG	CFM56-5B
CH31900-6	20049310	IGNITER PLUG	CFM56-5B
CH31900-6	19067155	IGNITER PLUG	CFM56-5B
CH31900-6	19067216	IGNITER PLUG	CFM56-5B
RP216-00	YC539779-4	T25 TEMPERATURE SENSOR	CFM56-5B
TC315-02	YC008641-LR	T495 THERMOCOUPLE WIRING	CFM56-5B
UL10470	271	BRAZO LATERAL	CFM56-5B
UL10470	404	BRAZO LATERAL	CFM56-5B
UL15271	AN1475	SOPORTE EXTERIOR	CFM56-5B
XX1476M79P03X	15-68288/2-2	SLEEVE FORWARD SLEEVE	CFM56-5B
1558M31G07	GWNOPROP	SPOOL STG. 1-2	CFM56-7B
1795M36P02	TMTNM950	SEAL ROTATING HPT	CFM56-7B
1853M10G03	PPBYP499	No 3 BRG ST Seg	CFM56-7B
2410M50P02	TMT3AR75	SEAL ROTATING HPT	CFM56-7B
2410M50P02	TMT5DA06	SEAL ROTATING HPT	CFM56-7B
335-192-202-0	MC039143	VANE, ASSY-STG 2	CFM56-7B
336-001-804-0	PA306162	DISK-LPT STG 1	CFM56-7B
336-001-909-0	PA312734	DISK-LPT STG 2	CFM56-7B
336-002-006-0	PA273055	DISK-LPT STG 3	CFM56-7B
336-002-105-0	PA282787	DISK-LPT STG 4	CFM56-7B
338-077-502-0	PA226776	SUPPORT-RTR LPT	CFM56-7B
340-058-302-0	PA018260	VANE, ASSY-FAN BSTR STG 3	CFM56-7B
340-058-402-0	PA018994	VANE, ASSY-STG 4	CFM56-7B
340-074-723-0	PA290519	SHAFT, LPT	CFM56-7B
340-170-301-0	1201	TUBE, VENT	CFM56-7B
CA243-01	YH672609-2	T495 THERMOCOUPLE WIRING HARNESS	CFM56-7B
CA244-02	DH947610-H	FIRE DETECTION HARNESS	CFM56-7B
1018328	3CAAB11226	IGNITER PLUG-GAS TURBINE ENGINE	PW1100
1033753	3CAAB03579	IGNITER PLUG-GAS	PW1100
1033753	3CAAT01084	IGNITER PLUG-GAS	PW1100
1033753	3CAAT02926	IGNITER PLUG-GAS	PW1100
1033753	3CAAT02988	IGNITER PLUG-GAS	PW1100
1033753	3CAAT03407	IGNITER PLUG-GAS	PW1100
1033753	3CAAT03411	IGNITER PLUG-GAS	PW1100

1033753	3CAAT07741	IGNITER PLUG-GAS	PW1100
1033753	3CAAT07742	IGNITER PLUG-GAS	PW1100
1033753	3CAAT13562	IGNITER PLUG-GAS	PW1100
1033753	3CAAT13563	IGNITER PLUG-GAS	PW1100
1033753	8CAAB09915	IGNITER PLUG-GAS	PW1100
5309257	LAAAN2002	BEARING - NO. 3 BALL	PW1100
5309262	LCWKAH7112	BEARING - BALL, ANNULAR, FLANGED	PW1100
5311239	LAEDAW2833	SEAT - NO. 1 BEARING SEAL	PW1100
5316828	LLDGAJ8436	SEAT - NO. 4 BEARING SEAL, FRONT	PW1100
5316828	LLDGAJ8647	SEAT - NO. 4 BEARING SEAL, FRONT	PW1100
5316828	LLDGAM6360	SEAT - NO. 4 BEARING SEAL, FRONT	PW1100
5316828	LLDGAP8177	SEAT - NO. 4 BEARING SEAL, FRONT	PW1100
5319625	LBDUA43401	BEARING SEAL SEAT	PW1100
5319625	LBDUAW0785	BEARING SEAL SEAT	PW1100
5319625	LBDUAW1104	BEARING SEAL SEAT	PW1100
5319625	LBDUAW1346	BEARING SEAL SEAT	PW1100
5319625	LBDUAW1393	BEARING SEAL SEAT	PW1100
5319625	LBDUBL1819	BEARING SEAL SEAT	PW1100
5321991	0A2XMD	SHIELD - HEAT, TIC	PW1100
5321991	0A6XB7	SHIELD - HEAT, TIC	PW1100
5321991	0A7L5X	SHIELD - HEAT, TIC	PW1100
5322121	JB1AEC3431	FAN BLADE ASSEMBLY	PW1100
5324005	LLDGAL8302	DAMPER - NO. 4 BEARING	PW1100
5326847	LCWKAM0201	SEAT - NO. 3 BEARING SEAL, FRONT	PW1100
5326847	LCWKAM0421	SEAT - NO. 3 BEARING SEAL, FRONT	PW1100
5326847	LCWKAM3354	SEAT - NO. 3 BEARING SEAL, FRONT	PW1100
5326847	LCWKAM4065	SEAT - NO. 3 BEARING SEAL, FRONT	PW1100
5326847	LCWKAM7213	SEAT - NO. 3 BEARING SEAL, FRONT	PW1100
5326847	LCWKAM7310	SEAT - NO. 3 BEARING SEAL, FRONT	PW1100
5326847	LCWKAM7313	SEAT - NO. 3 BEARING SEAL, FRONT	PW1100
5326847	LCWKAM8428	SEAT - NO. 3 BEARING SEAL, FRONT	PW1100
5326847	LCWKAN1401	SEAT - NO. 3 BEARING SEAL, FRONT	PW1100
5326847	LCWKAN3834	SEAT - NO. 3 BEARING SEAL, FRONT	PW1100
5326847	LCWKAN4071	SEAT - NO. 3 BEARING SEAL, FRONT	PW1100
5327070	LCWKAK2396	SEAL - AIR, NO. 3 BEARING, ASSEMBLY	PW1100
5327070	LCWKAL9868	SEAL - AIR, NO. 3 BEARING, ASSEMBLY	PW1100
5327070	LCWKAM2467	SEAL - AIR, NO. 3 BEARING, ASSEMBLY	PW1100
5327070	LCWKAM3854	SEAL - AIR, NO. 3 BEARING, ASSEMBLY	PW1100
5327070	LCWKAM4132	SEAL - AIR, NO. 3 BEARING, ASSEMBLY	PW1100
5327070	LCWKAM4133	SEAL - AIR, NO. 3 BEARING, ASSEMBLY	PW1100
5327070	LCWKAM4909	SEAL - AIR, NO. 3 BEARING, ASSEMBLY	PW1100
5327070	LCWKAM5049	SEAL - AIR, NO. 3 BEARING, ASSEMBLY	PW1100
5327070	LCWKAM5207	SEAL - AIR, NO. 3 BEARING, ASSEMBLY	PW1100
5327070	LCWKAM6408	SEAL - AIR, NO. 3 BEARING, ASSEMBLY	PW1100
5327070	LCWKAM8743	SEAL - AIR, NO. 3 BEARING, ASSEMBLY	PW1100
5327070	LCWKAN0017	SEAL - AIR, NO. 3 BEARING, ASSEMBLY	PW1100
5327070	LCWKAN0275	SEAL - AIR, NO. 3 BEARING, ASSEMBLY	PW1100
5327070	LCWKAN2497	SEAL - AIR, NO. 3 BEARING, ASSEMBLY	PW1100
5327070	LCWKAN2628	SEAL - AIR, NO. 3 BEARING, ASSEMBLY	PW1100
5327070	LCWKAN2736	SEAL - AIR, NO. 3 BEARING, ASSEMBLY	PW1100
5327070	LCWKAN2891	SEAL - AIR, NO. 3 BEARING, ASSEMBLY	PW1100
5327070	LCWKAN6436	SEAL - AIR, NO. 3 BEARING, ASSEMBLY	PW1100

Перечень компонентов, запрещенных к установке на воздушные суда

5327070	LCWKAN6438	SEAL - AIR, NO. 3 BEARING, ASSEMBLY	PW1100
5327070	LCWKAP0891	SEAL - AIR, NO. 3 BEARING, ASSEMBLY	PW1100
5327070	LCWKAP1671	SEAL - AIR, NO. 3 BEARING, ASSEMBLY	PW1100
5327070	LCWKAP1672	SEAL - AIR, NO. 3 BEARING, ASSEMBLY	PW1100
5327070	LCWKAP1685	SEAL - AIR, NO. 3 BEARING, ASSEMBLY	PW1100
5327070	LCWKAP2478	SEAL - AIR, NO. 3 BEARING, ASSEMBLY	PW1100
5327284	LCWKAM2161	SEAT - NO. 3 BEARING SEAL, REAR	PW1100
5327284	LCWKAM2207	SEAT - NO. 3 BEARING SEAL, REAR	PW1100
5327284	LCWKAM6644	SEAT - NO. 3 BEARING SEAL, REAR	PW1100
5327284	LCWKAM9392	SEAT - NO. 3 BEARING SEAL, REAR	PW1100
5327284	LCWKAN4868	SEAT - NO. 3 BEARING SEAL, REAR	PW1100
5328436	LAEDBF8385	SEAT - NO. 1 BEARING SEAL	PW1100
5328436	LAEDBG4964	SEAT - NO. 1 BEARING SEAL	PW1100
5328438	LLDGAL4996	SEAT - SEAL, NO. 4 BEARING, REAR	PW1100
5328438	LLDGAP8611	SEAT - SEAL, NO. 4 BEARING, REAR	PW1100
5328438	LLDGAR0519	SEAT - SEAL, NO. 4 BEARING, REAR	PW1100
5328438	LLDGAS7851	SEAT - SEAL, NO. 4 BEARING, REAR	PW1100
5372180	1T14045	STRUCTURAL GUIDE VANE ASSEMBLY (SGV)	PW1100
5372180	1T16798	STRUCTURAL GUIDE VANE ASSEMBLY (SGV)	PW1100
1020892-3	LSGCAX9213	PROBE-SPEED NFAN	PW1100
1020903-1	3MCAE00290	AFT VIBRATION SENSOR	PW1100
1020923-1	LSGCAS7288	BUFFER AIR VALVE	PW1100
1020923-1	LSGCAW4824	BUFFER AIR VALVE	PW1100
1020923-1	LSGCAW4862	BUFFER AIR VALVE	PW1100
1022311-1	LSGCAU1591	VALVE OIL, MAIN GEARBOX CHECK ASSY OF	PW1100
30G2461	LKLBC70505	SLEEVE - HPT, 2 STG	PW1100
30G4217	LKLBHB8267	SUPPORT SEGMENT - HPT, 1STG	PW1100
30G4217	LKLBHB8268	SUPPORT SEGMENT - HPT, 1STG	PW1100
30G4217	LKLBHB8297	SUPPORT SEGMENT - HPT, 1STG	PW1100
30G4217	LKLBHB8298	SUPPORT SEGMENT - HPT, 1STG	PW1100
30G4217	LKLBHC4479	SUPPORT SEGMENT - HPT, 1STG	PW1100
30G4217	LKLBHC4481	SUPPORT SEGMENT - HPT, 1STG	PW1100
30G4217	LKLBHC4482	SUPPORT SEGMENT - HPT, 1STG	PW1100
30G4217	LKLBHC4483	SUPPORT SEGMENT - HPT, 1STG	PW1100
30G4217	LKLBHC4484	SUPPORT SEGMENT - HPT, 1STG	PW1100
30G4217	LKLBHC4485	SUPPORT SEGMENT - HPT, 1STG	PW1100
30G4217	LKLBHC4486	SUPPORT SEGMENT - HPT, 1STG	PW1100
30G4217	LKLBHC4488	SUPPORT SEGMENT - HPT, 1STG	PW1100
30G4217	LKLBHC4945	SUPPORT SEGMENT - HPT, 1STG	PW1100
30G4217	LKLBHC4946	SUPPORT SEGMENT - HPT, 1STG	PW1100
30G4217	LKLBHH1701	SUPPORT SEGMENT - HPT, 1STG	PW1100
30G4217	LKLBHH1703	SUPPORT SEGMENT - HPT, 1STG	PW1100
30G4217	LKLBHH1706	SUPPORT SEGMENT - HPT, 1STG	PW1100
30G4217	LKLBHH1719	SUPPORT SEGMENT - HPT, 1STG	PW1100
30G4217	LKLBHR2189	SUPPORT SEGMENT - HPT, 1STG	PW1100
30G4217	LKLBHR2741	SUPPORT SEGMENT - HPT, 1STG	PW1100
30G4217	LKLBHR2836	SUPPORT SEGMENT - HPT, 1STG	PW1100
30G4217	LKLBHR2999	SUPPORT SEGMENT - HPT, 1STG	PW1100
30G4217	LKLBHR8554	SUPPORT SEGMENT - HPT, 1STG	PW1100
30G4217	LKLBHR8555	SUPPORT SEGMENT - HPT, 1STG	PW1100
30G4217	LKLBHR8560	SUPPORT SEGMENT - HPT, 1STG	PW1100
30G4217	LKLBJ17244	SUPPORT SEGMENT - HPT, 1STG	PW1100

Перечень компонентов, запрещенных к установке на воздушные суда

30G4217	LKLBJ17246	SUPPORT SEGMENT - HPT, 1STG	PW1100
30G4217	LKLBJ17247	SUPPORT SEGMENT - HPT, 1STG	PW1100
30G4217	LKLBJ17255	SUPPORT SEGMENT - HPT, 1STG	PW1100
30G4217	LKLBJ21853	SUPPORT SEGMENT - HPT, 1STG	PW1100
30G4217	LKLBJ21884	SUPPORT SEGMENT - HPT, 1STG	PW1100
30G4217	LKLBJ21887	SUPPORT SEGMENT - HPT, 1STG	PW1100
30G4217	LKLBJ21891	SUPPORT SEGMENT - HPT, 1STG	PW1100
30G4276-01	LENCA88981	SEAL - HPC, 7 STG	PW1100
30G4407	LENCA69868	ROTOR-HPC 7TH STAGE	PW1100
30G5126	LENCA58157	SEAL - RING, HPC	PW1100
30G5801	LENCA61103	HUB - HPC, FRONT	PW1100
30G5801	LENCA62253	HUB - HPC, FRONT	PW1100
30G5801	LENCAT0364	HUB - HPC, FRONT	PW1100
30G6090	LENCA39437	SEAL - RING, HPC	PW1100
30G6090	LENCA86927	SEAL - RING, HPC	PW1100
30G6090	LENCA88234	SEAL - RING, HPC	PW1100
30G6090	LENCA92462	SEAL - RING, HPC	PW1100
30G6090	LENCAW1576	SEAL - RING, HPC	PW1100
30G6090	LENCAW7563	SEAL - RING, HPC	PW1100
30G6090	LENCAW5091	SEAL - RING, HPC	PW1100
31G0018	LKLBJA0608	PLATE - RETAINING,	PW1100
31G0101	LKLBF66785	BLADE - HPT, 1 STG	PW1100
31G0101	LKLBF3654	BLADE - HPT, 1 STG	PW1100
31G0101	LKLBF7744	BLADE - HPT, 1 STG	PW1100
31G0101	LKLBF7748	BLADE - HPT, 1 STG	PW1100
31G0101	LKLBF6146	BLADE - HPT, 1 STG	PW1100
31G0101	LKLBF6487	BLADE - HPT, 1 STG	PW1100
31G0101	LKLBF6737	BLADE - HPT, 1 STG	PW1100
31G0101	LKLBF7125	BLADE - HPT, 1 STG	PW1100
31G0101	LKLBF7157	BLADE - HPT, 1 STG	PW1100
31G0101	LKLBGG2653	BLADE - HPT, 1 STG	PW1100
31G0101	LKLBGG4230	BLADE - HPT, 1 STG	PW1100
31G0101	LKLBGG4762	BLADE - HPT, 1 STG	PW1100
31G0101	LKLBGG5861	BLADE - HPT, 1 STG	PW1100
31G0101	LKLBM8470	BLADE - HPT, 1 STG	PW1100
31G0101	LKLBN0426	BLADE - HPT, 1 STG	PW1100
31G0101	LKLBN0670	BLADE - HPT, 1 STG	PW1100
31G0101	LKLBN0934	BLADE - HPT, 1 STG	PW1100
31G0101	LKLBN1633	BLADE - HPT, 1 STG	PW1100
31G0101	LKLBN1635	BLADE - HPT, 1 STG	PW1100
31G0101	LKLBN1663	BLADE - HPT, 1 STG	PW1100
31G0101	LKLBN1730	BLADE - HPT, 1 STG	PW1100
31G0101	LKLBN1757	BLADE - HPT, 1 STG	PW1100
31G0101	LKLBN1857	BLADE - HPT, 1 STG	PW1100
5312695-01	LAEDBJ4169	SEAL (OPTIONAL PART)	PW1100
5322004-01	LLDGAR2057	CASE - TURBINE	PW1100
636-5313-501	0000440	DUCT ASSY-NAI	PW1100
636D0002-519	201315	NACELLE ANTI-ICE SOLENOIDS MANIFOLD	PW1100
0205K0S600	1504034	SWITCH O/H DET HP/IPT DISC	RB211-535E4
21SN04-104D	J111A	PRESSURE SWITCH ASSEMBLY	RB211-535E4
21SN04-104D	P1369	PRESSURE SWITCH ASSEMBLY	RB211-535E4
CH34743	20003908	PLUG IGNITER	RB211-535E4

D3292-4000A	M100398	COOLER OIL-AIR COOLED IDG	RB211-535E4
FB222112	EZQD11	BEARING BALL IP LOCATION	RB211-535E4
FB222165	FIPJ39	BEARING BALL	RB211-535E4
FW16689	SETM08774/A	DISCO LPT 2	RB211-535E4
FW29138	CN62962907	LPT SHAFT INTERIOR TUBE	RB211-535E4
FW30433	BAEF6422A	SHAFT LPT	RB211-535E4
FW62968	20229916442	BEARING HOUSING	RB211-535E4
FW62968	202299137284	BEARING HOUSING	RB211-535E4
LK74826	DPQD66	BEARING	RB211-535E4
LK74930	AD950-1C181	BEARING ROLLER	RB211-535E4
LK83059	00043	BEARING HOUSING	RB211-535E4
N14FF104	1414R	THROTLER ANGLE TRANSDUCER	RB211-535E4
UL18114	MW0067138	DISCO HPC 4-6	RB211-535E4
UL29031	SETY01683	DISCO LPT 3	RB211-535E4
UL30176	DN65325	DISCO 1-6	RB211-535E4
UL31991	303471	CARTER STG 2 - 6	RB211-535E4
UL37300	G/LJ1409	SHROUD STG 2	RB211-535E4
UL37300	G/LJ1284	SHROUD STG 2	RB211-535E4
UL37571	BAEF4936	SHAFT IPT	RB211-535E4
UL38395	00378RC18	BLADES HPT	RB211-535E4
UL38395	00726RC10	BLADES HPT	RB211-535E4
UL38395	00743RC4	BLADES HPT	RB211-535E4
UL38395	00748RC12	BLADES HPT	RB211-535E4
UL38395	00854RC4	BLADES HPT	RB211-535E4
UL38395	00864RC12	BLADES HPT	RB211-535E4
UL38395	00865RC15	BLADES HPT	RB211-535E4
UL38395	00882RC8	BLADES HPT	RB211-535E4
UL38395	00886RC4	BLADES HPT	RB211-535E4
UL38395	00887RC7	BLADES HPT	RB211-535E4
UL38395	00898RC2	BLADES HPT	RB211-535E4
UL38395	00945RC3	BLADES HPT	RB211-535E4
UL38395	06009C7	BLADES HPT	RB211-535E4
UL38395	06025C17	BLADES HPT	RB211-535E4
UL38395	06049C14	BLADES HPT	RB211-535E4
UL38395	06087C14	BLADES HPT	RB211-535E4
UL38395	06087C5	BLADES HPT	RB211-535E4
UL38395	06089C17	BLADES HPT	RB211-535E4
UL38395	06095C5	BLADES HPT	RB211-535E4
UL38395	06095C6	BLADES HPT	RB211-535E4
UL38395	06116C4	BLADES HPT	RB211-535E4
UL38395	06139C2	BLADES HPT	RB211-535E4
UL38395	06148C12	BLADES HPT	RB211-535E4
UL38395	06148C15	BLADES HPT	RB211-535E4
UL38395	06148C20	BLADES HPT	RB211-535E4
UL38395	06148C8	BLADES HPT	RB211-535E4
UL38395	06149C1	BLADES HPT	RB211-535E4
UL38395	06149C7	BLADES HPT	RB211-535E4
UL38395	06151C15	BLADES HPT	RB211-535E4
UL38395	06165C10	BLADES HPT	RB211-535E4
UL38395	06165C12	BLADES HPT	RB211-535E4
UL38395	06165C13	BLADES HPT	RB211-535E4
UL38395	06165C14	BLADES HPT	RB211-535E4

UL38395	06165C15	BLADES HPT	RB211-535E4
UL38395	06165C8	BLADES HPT	RB211-535E4
UL38395	06167C11	BLADES HPT	RB211-535E4
UL38395	06169C5	BLADES HPT	RB211-535E4
UL38395	06179C11	BLADES HPT	RB211-535E4
UL38395	06179C2	BLADES HPT	RB211-535E4
UL38395	06179C5	BLADES HPT	RB211-535E4
UL38395	06194C4	BLADES HPT	RB211-535E4
UL38395	06195C2	BLADES HPT	RB211-535E4
UL38395	06195C3	BLADES HPT	RB211-535E4
UL38395	06195C8	BLADES HPT	RB211-535E4
UL38395	06202C15	BLADES HPT	RB211-535E4
UL38395	06202C17	BLADES HPT	RB211-535E4
UL38395	06203C2	BLADES HPT	RB211-535E4
UL38395	06203C4	BLADES HPT	RB211-535E4
UL38395	06203C6	BLADES HPT	RB211-535E4
UL38395	06216C15	BLADES HPT	RB211-535E4
UL38395	06216C20	BLADES HPT	RB211-535E4
UL38395	06219C3	BLADES HPT	RB211-535E4
UL38395	06221C13	BLADES HPT	RB211-535E4
UL38395	06221C16	BLADES HPT	RB211-535E4
UL38395	06267C18	BLADES HPT	RB211-535E4
UL38395	06270C1	BLADES HPT	RB211-535E4
UL38395	06270C13	BLADES HPT	RB211-535E4
UL38395	13385C16	BLADES HPT	RB211-535E4
UL38395	13824C16	BLADES HPT	RB211-535E4
UL38395	13845C10	BLADES HPT	RB211-535E4
UL38395	13997C8	BLADES HPT	RB211-535E4
UL38395	14050C17	BLADES HPT	RB211-535E4
UL38395	14101C14	BLADES HPT	RB211-535E4
UL38395	14101C15	BLADES HPT	RB211-535E4
UL38395	14195C15	BLADES HPT	RB211-535E4
UL38395	14196C5	BLADES HPT	RB211-535E4
UL38395	14196C6	BLADES HPT	RB211-535E4
UL38395	14414C19	BLADES HPT	RB211-535E4
UL38395	14446C8	BLADES HPT	RB211-535E4
UL38395	14452C20	BLADES HPT	RB211-535E4
UL38395	14487C11	BLADES HPT	RB211-535E4
UL38395	14499C12	BLADES HPT	RB211-535E4
UL38395	14499C13	BLADES HPT	RB211-535E4
UL38395	14500C2	BLADES HPT	RB211-535E4
UL38395	14501C4	BLADES HPT	RB211-535E4
UL38395	14510C11	BLADES HPT	RB211-535E4
UL38395	14516C15	BLADES HPT	RB211-535E4
UL38395	14521C13	BLADES HPT	RB211-535E4
UL38395	14542C5	BLADES HPT	RB211-535E4
UL38395	14542C6	BLADES HPT	RB211-535E4
UL39767	LDRCZ15439	DISCO HPT	RB211-535E4
190130	P19-00061	TERMOCOUPLE EGT	V2500
190130	P19-00071	TERMOCOUPLE EGT	V2500
190130	P19-00072	TERMOCOUPLE EGT	V2500
190130	P19-00097	TERMOCOUPLE EGT	V2500

Перечень компонентов, запрещенных к установке на воздушные суда

190130	PIT-00343	TERMOCOUPLE EGT	V2500
190130	PIT-00397	TERMOCOUPLE EGT	V2500
12536-16844-000	7010	COOLER IDG OIL-FUEL COOLED	V2500
144-171-000-031	AK07938	VIBRATION TRANSDUCER	V2500
144-171-000-031	0539	VIBRATION TRANSDUCER	V2500
2A3423	PKLBKE2518	SEAL AIR HPT-1	V2500
2A3499	2525L	SEAL, ASSY OF,FACE;#4 BRG	V2500
2A3499	11739L	SEAL, ASSY OF,FACE;#4 BRG	V2500
2A3543	PGGUAJ8603	SEAL, RING HOLDER	V2500
2A4157	PKLBJE6800	SEAL AIR HPT-2	V2500
2A4157	PKLBH32448	SEAL AIR HPT-2	V2500
2A4157	PKLBJ79027	SEAL AIR HPT-2	V2500
2A4802	PKLBKU8651	HUB HPT-2	V2500
2A4802	PKLBKU9232	HUB HPT-2	V2500
2A4802	PKLBKY6744	HUB HPT-2	V2500
2A4802	PKLBF97984	HUB HPT-2	V2500
2A5001	PKLBF73276	HUB HPT-1	V2500
2A5001	PKLBR59992	HUB HPT-1	V2500
30030-000	1076758	THERMO COUPLE	V2500
30030-000	1099212	THERMO COUPLE	V2500
30030-000	1101860	THERMO COUPLE	V2500
30030-000	1101869	THERMO COUPLE	V2500
30030-000	1101871	THERMO COUPLE	V2500
30030-000	1101874	THERMO COUPLE	V2500
30030-000	PSGCAR3429	THERMO COUPLE	V2500
30030-000	PSGCAR4995	THERMO COUPLE	V2500
30030-000	PSGCAR4996	THERMO COUPLE	V2500
30030-000	PSGCAR4998	THERMO COUPLE	V2500
30030-000	1063000	THERMO COUPLE	V2500
30040-000	1075268	THERMO COUPLE	V2500
30040-000	1103129	THERMO COUPLE	V2500
30404-000	1164638	THERMO COUPLE PROBE ASSEMBLY	V2500
30404-000	1163164	THERMO COUPLE PROBE ASSEMBLY	V2500
30404-000	1167960	THERMO COUPLE PROBE ASSEMBLY	V2500
30404-000	1166356	THERMO COUPLE PROBE ASSEMBLY	V2500
30558-000	1138693	EGT HARNESS AND JUNCTION BOX	V2500
30558-000	1153797	EGT HARNESS AND JUNCTION BOX	V2500
30558-000	1168526	EGT HARNESS AND JUNCTION BOX	V2500
3A2430	MAG59444	DISC LPT-5 (PVL CAJA)	V2500
3A2996	MAG62452	DISC LPT-6 (PVL CAJA)	V2500
512090-1	S19200307	IGNITION LEAD	V2500
512090-1	S19370174	IGNITION LEAD	V2500
512090-1	S21460218	IGNITION LEAD	V2500
512090-1	S23420048	IGNITION LEAD	V2500
512090-1	S23480459	IGNITION LEAD	V2500
512090-1	S23480460	IGNITION LEAD	V2500
512090-1	Y23167	IGNITION LEAD	V2500
5950041-108	2493	HP10 BLEED VALVE	V2500
5W2198	JM5249	CASE, ASSY OF LPC MID	V2500
6773F010000	6773-11710	HP BLEED VALVE	V2500
6A5682	RRC6CC37	HPC REAR OUTER CASE	V2500
6A5878	12618	EGT ELECTRICAL HARNESS	V2500

6A5878	11456	EGT ELECTRICAL HARNESS	V2500
6A7546	RMW0059933	STAGE 9 TO 12 DISK	V2500
6A7614	RGV51784	BLADE, ASSY	V2500
6A8162	MK01041	HPC REAR OUTER CASE	V2500
6B1404	RRD6409	STAGE 3 TO 8 DISK	V2500
6B1404	RRD6529	STAGE 3 TO 8 DISK	V2500
6B1404	RRD6559	STAGE 3 TO 8 DISK	V2500
6B1404	RRD6655	STAGE 3 TO 8 DISK	V2500
6B1404	RRD6778	STAGE 3 TO 8 DISK	V2500
6B1404	RRD7743	STAGE 3 TO 8 DISK	V2500
6B1404	RRD9343	STAGE 3 TO 8 DISK	V2500
6B1404	RRD6456	STAGE 3 TO 8 DISK	V2500
6B1404	RRD6591	STAGE 3 TO 8 DISK	V2500
6B1404	RRD7183	STAGE 3 TO 8 DISK	V2500
790425A6	PS4-0296	STARTER PNEUMATIC	V2500
792-6-20	PSGCAL5444	T4.9 THERMOCOUPLE	V2500
9045405-7	Y0515	IGNITION LEADS	V2500
AC69924	ELU072	HP7 BLEED VALVE	V2500
CH53564-1	22040717	PLUG IGNITER	V2500
PG9903-300-40105	DTAR985	NO. 4 BEARING PRESSURE TRANSDUCER	V2500
RP162-02	8676	NACELLE TEMPERATURE SENSOR	V2500
RP162-02	12613	NACELLE TEMPERATURE SENSOR	V2500
RP162-02	13003	NACELLE TEMPERATURE SENSOR	V2500
RP162-02	12134	NACELLE TEMPERATURE SENSOR	V2500